

European Engine Management Program



Cam & Crank Sensors

342 European SKUs Available

Determines the camshaft and crankshaft position and sends this information to the onboard computer. The computer uses this and other inputs to calculate injector on time and ignition system timing.

Mass Air Flow Sensors

285 European SKUs Available MAF measures the amount of the air by weight through changing voltages or frequencies and sends this information to the onboard computer. The computer uses this and other inputs to calculate the correct amount of fuel delivered.

Coils, COP & Cassette

89 European SKUs Available

Ignition coils receive input from the ECU telling it when to close & open the circuit connection to release the charge to a spark plug wire or distributor (coil pack), or directly to the spark plug (coil on plug).



Throttle Position Sensors

34 European SKUs Available

Measures throttle position through changing voltage and sends this information to the onboard computer. The computer uses this and other inputs to calculate the correct amount of fuel delivered.



Engine Coolant Temperature Sensors

48 European SKUs Available

Measures coolant temperature through changing resistance and sends this information to the onboard computer. The computer uses this and other inputs to calculate the correct amount of fuel delivered.



WALKER PRODUCTS, INC. • EUROPE OPERATIONS

7 CASTLE ROAD • KINGS NORTON BUSINESS CENTRE BIRMINGHAM, B30 3HZ • WEST MIDLANDS, UK Office: +44-121-459-8006 • saleseurope@walkerproducts.com



QUALITY · COVERAGE · SUPPORT

© 2025 Walker Products, Inc. All rights reserved. WF27-129E